


KitchenAid®

OVEN PARTS

For Models: KEHU309SSS02
(Stainless)

30" BUILT-IN ELECTRIC
COMBINATION OVEN
CONVECTION MICROWAVE UPPER



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN PARTS

For Models: KEHU309SSS02
(Stainless)

Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	W10140564	Installation Instructions
		Use & Care Guide
	W10162201	Oven
	W10138787	Microwave
		Tech Sheet
	W10220958	English
	W10220959	French
		Safer Cooking Tips
	9762761	English
	W10065852	French
2	W10153090	Bracket, Base
3		Hinge Receiver
	4455606	Right
	4455605	Left
4	W10105790	Bumper, Door (2)
5	8303829	Exhaust, Vent Slope
6	W10181196	Divider, Vent
7	W10204470	Top Chassis
8	4449809	Screw
9	3196176	Screw
10	4452163	Lens, Light
11	4448972	Oven Light, Assembly
12	4452164	Bulb, Light

Illus. No.	Part No.	DESCRIPTION
13	3400832	Screw
14	W10115861	Frame, Front
15	8304493	Gasket, Door
16	4452158	Tube, Vent
17	4449040	Screw
18	3400893	Screw
19	4451478	Support, Insulation
20	8303685	Center Vent
21		Mounting Rail, Side
	8303679BL	Right
	8303680BL	Left
22	8303692	Latch, Mortorized
23	4449743	Screw
24	4448444	Mounting Grommet, Rail (6)
25	4455641	Side, Chassis
26	W10153104	Back, Chassis
27		Liner, Oven (Not serviceable)
28	8304452	Thermal Fuse
29	W10131825	Sensor
30	4449748	Screw
31	8303516	Base, Chassis
32	W10153361	Retainer, Gasket
33	8303517	Cover, Back
34	W10216230	Trim, Bottom Vent
35	9758597	Orifice, Boiler Slip Fit

Illus. No.	Part No.	DESCRIPTION
36	W10153098	Cover, Boiler Orifice
37	8304640	Screw
38	W10155510	Enclosure
39	W10077010	Gasket, Enclosure
40	W10111418	Valve, Solenoid
41	W10076760	Sensor, Conductivity Slip Fit
42	W10169348	Bracket, Thermostat
44	W10076910	Tubing
45	9761146	Clamp, Crimp
46	9758598	Boiler Assembly
47	W10194453	Switch, Pressure
48	W10076930	Hose (includes clamp)
49	W10142627	Tube-Copper, Steam
50	4450038	Screw

FOLLOWING PARTS NOT ILLUSTRATED


INSULATION

8303965	Insulation, Wrap
W10141379	Insulation, Back

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PANEL PARTS


For Models: KEHU309SSS02
(Stainless)



Illus. No.	Part No.	DESCRIPTION
1	W10216219	Panel, Control
4	W10110694	Control Panel, Glass Touch
5	W10143290	User Interface
6	8303719	Backer, Control
7	8303887	Bracket, Enclosure
8	4449154	Screw
9	3400832	Screw
10	W10160958	Appliance Manager
11	8304441	Resistor, Drop
12	W10134765	Vapor, Stop
13	3400805	Screw
15	4449809	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST


**For Models: KEHU309SSS02
(Stainless)**



W10243115

INTERNAL OVEN PARTS

For Models: KEHU309SSS02
(Stainless)



Illus. No.	Part No.	DESCRIPTION
1	9760774	Element, Broil
2	8303841	Rack, Oven
3	9760768	Element, Bake
4	4455037	Tray, Bake
5	4449154	Screw
6	4450039	Cover, Bake Tray
7	4449809	Screw
8	W10196895	Motor, Convection Fan


Illus. No.	Part No.	DESCRIPTION
9	W10116351	Blade, Fan
10	W10116349	Nut
11	W10141211	Cover, Fan
12	3400968	Nut
13	W10150011	Jack, Meat Probe
14	9755547	Lockwasher
15	9755546	Locknut

Illus. No.	Part No.	DESCRIPTION
16	8304602	Shield, Broil
17	W10153105	Plate, Mounting Convection Fan
18	W10116434	Element, Convection
19	9755542	Probe, Temperature

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP VENTING PARTS

For Models: KEHU309SSS02
(Stainless)



Illus. No.	Part No.	DESCRIPTION
1	4449154	Screw
2	4454949	Holder, Fuse
3	4449809	Screw
4	8303972	Blower
5	9760588	Transformer, Lights
6	8304643	Exhaust Vent


Illus. No.	Part No.	DESCRIPTION
7	9762885	Transformer, Control
8	8285593	Control Cover
9	4449868	Block, Terminal
10	W10017410	Fuse
11	8304509	Back Chassis Panel

Illus. No.	Part No.	DESCRIPTION
12	8304546	Side, Combo Right
	8303539	Left
13	8303537	Back, Control
14	8303519	Cover, Top Rear
15	7103P027-60	Nut
16	8304569	Support (2)
17	3400080	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET AND STIRRER PARTS

For Models: KEHU309SSS02
(Stainless)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET AND STIRRER PARTS


For Models: KEHU309SSS02
(Stainless)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	W10120227	Control, Electric	25	8205685	Spring	48	W10130903	Cover, Plate
2	8205669	Support	26	8205658	Housing, Lamp	49	W10130904	Cover, Rear
3	W10130892	Plate, Air	27	4375348	Lamp	50	8205680	Cover, Side Right
4	W10130901	Insulation, Side Left	28	W10120222	Thermostat	51	W10120221	Convection, Motor Assmebly
5	W10120471	Cover, Side Left	29	W10131248	Switch	52	8205721	Blower Assembly
6	W10120223	Thermostat	30	8205683	Holder, Switch	53	W10130907	Cover, Inverter
7	W10120224	Element, Convection	31	4375320	Reflector	54	W10120229	Inverter
8	4375418	Fan	32	4375318	Lens, Lamp	55	W10130906	Holder, Inverter
9	W10120233	Nut, Speed	33	W10120231	Clip, Spring	56	W10130890	Screw
10	W10130891	Holder	34	W10120477	Top Vent	57	W10130908	Baffle, Air
11	W10120220	Noise Filter	36		Trim, Side	58	W10130899	Plate, Air
12	W10120228	Control, Electric Converter		W10120473	Right	59	W10120235	Rod, Release
13	W10130909	Bracket, Support		W10120475	Left	60	W10120225	Sensor
14	W10131249	Screw	37	W10120469	Bushing	61	8205685	Spring
15	8205692	Transformer	38	W10130905	Bracket, Support	64	8205683	Interlock
16	4375427	Actuator	39	8205708	Bracket, Support	65	W10130900	Insulation
17	4375321	Fuse	40	8205682	Shaft, Turntable	66	8205704	Spring
18	4375231	Block, Fuse			Turntable	67	W10130902	Insulation
19	W10130897	Bracket, Support	41	8205681	Cover, Motor	68	8205689	Spring
20	8205653	Filter, Noise			Turntable	69	8205688	Arm
21	8205654	Thermostat	42	W10120234	Cover	70	8205686	Support
22	W10120113	Magnetron	43	4375252	Gasket, Shaft	71	W10120236	Arm
23	W10130895	Plate, Air	44	8205655	Motor, Turntable	72	W10120470	Pin, Damper
24	4375319	Spring, Lamp	45	4375202	Screw	73	8205690	Sensor
			46	8205707	Support	74	W10130898	Duct, Magnetron
			47	W10120478	Hinge, Door			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

INTERNAL MICROWAVE PARTS

For Models: KEHU309SSS02
(Stainless)




Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

- | | | |
|----|-----------|-------------------|
| 1 | W10120480 | Crisp Plate |
| 2 | W10120484 | Steamer |
| 3 | 4452220 | Rack, Convection |
| 4 | W10120486 | Plate, Baking |
| 5 | W10120483 | Rack |
| 6 | 8205676 | Turntable |
| 7 | 8205678 | Ring |
| 8 | 8205677 | Drive, Turn Table |
| 9 | W10120481 | Handle, Pan |
| 10 | W10120226 | Grill Heater |
| 11 | W10120230 | Cover, Plates (2) |
| 12 | W10120232 | Bracket, Mounting |

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MICROWAVE DOOR PARTS

For Models: KEHU309SSS02
(Stainless)



Illus. No.	Part No.	DESCRIPTION
	1	8304588BL Button, Plug (2)
	2	4449809 Screw
	3	W10216226 Door, Microwave
	4	4449154 Screw (4)
	5	8303033 Bracket, Handle
	6	8304026 Glass Assembly
	7	8303774SS Handle, Door
	8	W10143304 Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS

For Models: KEHU309SSS02
(Stainless)

Illus.	Part
No.	No. DESCRIPTION

PAINT, TOUCH-UP (1/2oz.)

72017 White
261869 Cord Brown
72032 Black

PAINT, SPRAY

350930 White
261900 Citrine White
830864 Black

ADHESIVE

591014 Adhesive
Loctite (1/3 oz.)
482338 Sealer, Silastic
(3 oz.)

WIRING HARNESS PARTS

W10143473 Harness, Latch
W10143472 Harness, Main
W10140602 Harness, Ultima
Combo
4452400 Lead, Ground Strap
8304597 Harness, Valve
8304340 Communication,
Harness
8304440 Conduit, Combo
4450800 Screw, Ground
4454842 Tie, Cable

Miscellaneous

W10111330 Filter, Cartridge
W10051680 Reducer, Stem
W10049700 Filter Assembly
W10076960 Elbow, Plug In

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST